WVI00031



The ZEN FF PLUS VISOR mounted on the QUANTUM helmet, via the EASY CLICK ADAPTERS FR, makes the helmet usable for use in wildland firefighting (EN16471) and technical rescue activities (EN16473) where there is potential exposure to flames.

TECHNICAL DETAILS



Standard.

MATERIAL

Polycarbonate



STANDARD

EN 14458

TEMPERATURE OF USE

-30°C / +50°C

OPTICAL CLASS

EN 166 EN 170 (clear) EN 172 (smoke, mirror)

ANSI Z87.1



WEIGHT

145 g



CATEGORY

TECHNOLOGIES



ANTI-FOG

Equipped with an anti-fog treatment to increase wearer visibility when active and in a variety of conditions.



DRIP PROOF UPPER CONTOUR

Designed with a rubber upper contour to keep out sweat moisture and to enhance comfort.



PANORAMIC LENS

Wide view lens for optimal protection and visibility.



SCRATCH RESISTANT

Equipped with a scratch-resistant treatment for increased durability.



COMPATIBLE WITH GLASSES

Designed for use over corrective glasses.



EASY CLICK ADAPTERS FR

Fire-resistant and designed to easily attach and remove KASK eye and face protection accessories. Compatible with all Quantum helmets

MARKINGS

CODE	COLOR	MARKINGS
WVI00031-500	CLEAR	EN14458:2018 KASK ZEN FF PLUS 22/10 +R1 @ BTKN 2C-1,2 -30°C+50°C E1/E3
		CE 2754 UKCA 2C-1,2 KASK EN166 1BT39KN / ANSI Z87+ U6 X D3
WVI00031-510	SMOKE	EN14458:2018 KASK ZEN FF PLUS 22/10 +R1 ⊕ BTKN 5-2 -30°C+50°C E1/E3
		CE 2754 UKCA 5 -2 KASK EN166 1BT39KN / ANSI Z87+ U6 L2 X D3

ADDITIONAL INFORMATION

GUARANTEE

3 years from date of purchase

10 years starting from the date of manufacture. Shelf life depends on various factors that can cause deterioration such as sudden temperature changes, the amount of exposure to direct sunlight and the intensity of use. Altered vision and scratches are elements that signal the need to check for deterioration of the visor.

CLEANING

Clean only with water and mild soap. Allow to air dry. Do not use chemical detergents, solvents, petrol powders as they are too aggressive and could lower the structural resistance of the visor. Do not rub the lens when dry.

ZEN PLUS FF VISOR COLLECTION



WVI00031-500



WVI00031-500



DISCOVER MORE





SCAN FOR COMPLETE COLLECTION









